


VILLAGE LIMITS BUFFER

BUFFER ZONE

BUFFER ZONE



1038 0.0' N 0.0' E 800.82	1034 0.1' N 0.0' E 800.69	1035 0.0' N 0.0' E 801.27	1097 0.0' N 0.0' E 803.26	1098 0.0' N 0.0' E 801.20	1099 0.0' N 0.0' E 801.63	1100 0.1' N 0.1' W 800.85	976 0.0' N 0.0' E 804
------------------------------------	------------------------------------	------------------------------------	------------------------------------	------------------------------------	------------------------------------	------------------------------------	--------------------------------